


WCM RGB LED Color/Button Guide

 **White**
Bluetooth Pairing Mode (Advertising Bluetooth Connection)

 **Blue**
Bluetooth Client Connected

 **Amber**
Attempting Internet Connection / Firmware Update in Progress

 **Green**
Connected to AWS

 **Red**
Failed to Connect to Internet / Failed to Initialize

 **Blinking**
Ready

 **Solid**
Busy

Resetting the WCM:
Press the RESET button once

Remote -> Local
Press and Hold the MODE button AND toggle the RESET button once
Continue holding the MODE button until the LED turns White

Button Actions
Change from Local Bluetooth mode to Remote AWS mode:
Press and Hold the MODE button until the LED turns Amber

RGB LED Color Meanings

White

- Bluetooth Pairing Mode (Advertising Bluetooth Connection)

Blue

- Bluetooth Client Connected

Amber

- Attempting Internet Connection
or
- Firmware Update in Progress

Green

- Connected to AWS

Red

- Failed to Connect to Internet
or
- Failed to Initialize

*Blinking = Ready

*Solid = Busy

Button Actions

Change from Local Bluetooth mode to Remote AWS mode:

Press and Hold the MODE button until the LED turns Amber

Change from Remote AWS mode to Local Bluetooth mode:

Press and Hold the MODE button AND toggle the RESET button once

Continue holding the MODE button until the LED turns White

Resetting the WCM:

Press the RESET button once