

Inverter Won't
Connect to Wifi

Wifi Board Light on

No

Ensure Power is
getting to the Wifi
Board

Yes

Light is White or
blue

Yes

Press the mode
button on the wifi
board to change to
cloud mode (Amber)

No

Light is Amber

Yes

Searching for WiFi:
Check to see that
password is correct
and wifi strength
should be 20mb
download and 5mb
upload on 2.4ghz
frequency wifi

No

Light is Green

Yes

You are Connected
(possible website
issue)